



Exon flat mop pockets system

Semi-disposable microfibre cloth for pockets system, packed

Technical information

code	notes	cm (comm. sizes)	cm (real sizes)	C	pcs	kg	m³
00000731	1 pack with 50 pcs.	↕ 40 ↗ 13	↕ 42,5 ↗ 14	☐	10	7,4	0,071

SYSTEM

Flat mopping system with pockets, to be used either pre-soaked, soaked on demand with soaking station or with handles with tank
Ideal for environments with high risk contamination

GREEN BOX



DECITEX of the fibres

Microfibre: 0,53 DTX



Efficient: microfibre requires less chemical to remove dirt and bacteria, reducing water and chemical consumption

Analysis

The analysis of the mechanical action of the Exon cloth revealed a removal of Coronavirus 229E from steel surfaces of 99 % (test conducted by a specialised external laboratory)

The analysis of the mechanical action of the Exon cloth revealed a removal of up to 94.2% of the bacteria present on the surface (test conducted according to UNI EN 16615:2015 by a specialised external laboratory)

Advantages

- **Semi-disposable:** either disposable or washable up to 10 times
- **Highest hygiene:** microfibre penetrates into the microporosity of the floor, collecting dirt and more than 95% of bacteria
- **Easy:** mop changing is easy and quickly

Compatibility

Compatible with pockets system frames 40 cm

Material

Yarn: microfibre (100% polyester)

Packaging: [click here to see the environmental labelling of packaging](#)

Washing conditions

Guidelines for proper fibre maintenance

Follow the washing instructions (temperatures and dosage) on the laundry detergent packaging
Perform a pre-wash in cold water without laundry detergent to remove any residual product used during cleaning operations

Recommended use of professional textile laundry detergent

Do not use fabric softener

Do not use laundry detergents with Ph> 11

The use of laundry nets is recommended to speed up and make laundry operations more hygienic

Specific mop instructions



Washing temperature max 60° C




Bleaching possible, do not use chlorine



Tumble dry or in a dryer possible with low program

Related products



Wet Disinfection frame



Blik frame