



Exon flat mop micro strap tape system

Semi-disposable microfiber cloth for micro strap tape system, packed



Technical information

code	notes	cm (comm. sizes)	cm (real sizes)	C	pcs	kg	m ³
00000733	1 pack with 50 pcs.	↙ 40 ↘ 13	↙ 42,5 ↘ 14	☐	10	6,31	0,065

SYSTEM

Flat mopping system with frame with micro-strap tape system, to be used either pre-soaked, soaked on demand with soaking station or with handles with tank
Ideal for environments with high risk contamination

GREEN BOX



DECITEX of the fibres
Microfibre: 0,53 DTX



Efficient: microfibre requires less chemical to remove dirt and bacteria, reducing water and chemical consumption

Analysis

Analysis of the mechanical action of the Exon flat mop alone revealed a 99.99% removal of bacteria and fungi present on the surface (test conducted by a specialised external laboratory adapting the UNI EN 16615:2015 standard).
The analysis of the mechanical action of the Exon cloth revealed a removal of Coronavirus 229E from steel surfaces of 99 % (test conducted by a specialised external laboratory)



29/10/25

Advantages

- **Highest hygiene:** Microfibre penetrates the micro-pores in the floor, collecting dirt and 99.99% of bacteria
- **Efficient:** designed to ensure optimum adherence to the frame
- **Easy:** mop changing is easy and quickly
- **Ergonomic:** it is the most lightweight system of TTS range
- **Semi-disposable:** either disposable or washable up to 10 times

Material

Microfibre (100% polyester)

Packaging: [click here to see the environmental labelling of packaging](#)

Features

Grammage: 195 gr/sqm

Washing conditions

Guidelines for proper fibre maintenance

Follow the washing instructions (temperatures and dosage) on the laundry detergent packaging
Perform a pre-wash in cold water without laundry detergent to remove any residual product used during cleaning operations
Recommended use of professional textile laundry detergent
Do not use fabric softener
Do not use laundry detergents with Ph > 11
The use of laundry nets is recommended to speed up and make laundry operations more hygienic

Specific mop instructions



Washing temperature max 60° C



Bleaching possible, do not use chlorine




Tumble dry or in a dryer possible with low program



29/10/25

Related products



Exon frame