



Pockets system Ultrasafe WDS flat mop

Microfibre and polypropylene flat mop with polyester support with pockets and flaps, for R10/11 non-slip surfaces



Technical information

code	notes	cm (comm. sizes)	C	pcs	kg	m³
0000H310R		↙ 40 ↘ 14		25	2,88	0,027
0000H310B		↙ 40 ↘ 14		25	2,88	0,027

SYSTEM

Flat mopping system with pockets, to be used either pre-soaked, soaked on demand with soaking station or with handles with tank
Ideal for washing of non-slip or porous surfaces, suitable to remove ingrained dirt

GREEN BOX



EU Ecolabel Certificate



DECITEX of the fibres

Microfibre: 0,16 DTX - Polypropylene: 37,03 DTX



Efficient: microfibre requires less chemical to remove dirt and bacteria, reducing water and chemical consumption



27/06/24

Advantages

- **Long durability:** pocket mops last twice as much as strap tape mops
- **Easy:** mop changing is easy and quickly
- **Effective:** the abrasive action of polypropylene removes easily dirt
- **Highest hygiene:** microfibre penetrates into the microporosity of the floor, collecting dirt and more than 95% of bacteria
- **Very low friction:** glides effortlessly on non-slip surfaces
- **Touch-free:** the detaching system avoids any contact with the dirt

Material

Yarn: 50% polypropylene, 40% polyester, 10% polyamide - Support: polyester

Packaging: [click here to see the environmental labelling of packaging](#)

Warnings

Use alkaline detergents with a pH below 11

Washing conditions

Guidelines for proper fibre maintenance

Follow the washing instructions (temperatures and dosage) on the laundry detergent packaging

Perform a pre-wash in cold water without laundry detergent to remove any residual product used during cleaning operations

Recommended use of professional textile laundry detergent

Do not use fabric softener

Do not use laundry detergents with Ph > 11

The use of laundry nets is recommended to speed up and make laundry operations more hygienic

Specific mop instructions



Washing temperature max 90° C, recommended 60°



Bleaching possible, do not use chlorine



Tumble dry or in a dryer possible with low program



Related products



Wet Disinfection frame



Blik frame



Action Pro Tec



Tec wringer



BIO Blik Basic