



Uni System Ultrasafe flat mop

Microfibre and polypropylene flat mop with polyester support for R10/11 non-slip surfaces



Technical information

code	notes	cm (comm. sizes)	cm (real sizes)	C	pcs	kg	m³
0000H410R		↙ 40 ↘ 14	↙ 40 ↘ 13		25	3,11	0,019
0000H410B		↙ 40 ↘ 14	↙ 40 ↘ 13		25	3,11	0,019

SYSTEM

Flat mop system with micro-flaps, to be used with roll, jaw or flat wringer
Ideal for washing of non-slip or porous surfaces, suitable to remove ingrained dirt

GREEN BOX



EU Ecolabel Certificate



DECITEX of the fibres

Microfibre: 0,16 DTX - Polypropylene: 37,03 DTX



Efficient: microfibre requires less chemical to remove dirt and bacteria, reducing water and chemical consumption



27/06/24

Advantages

- **Handy:** flat mops are easy to attach thanks to the facilitated hook mechanism
- **Safe:** flat mop remains firmly attached during use, thanks to the anti-slip device
- **Effective:** the abrasive action of polypropylene removes easily dirt
- **Highest hygiene:** microfibre penetrates into the microporosity of the floor, collecting dirt and more than 95% of bacteria
- **Very low friction:** glides effortlessly on non-slip surfaces
- **Hygienic:** the dirty mop can be quickly detached, without any physical contact with dirt

Material

Yarn: 50% polypropylene, 40% polyester, 10% polyamide - Support: polyester

Packaging: [click here to see the environmental labelling of packaging](#)

Warnings

Use alkaline detergents with a pH below 11

Washing conditions

Guidelines for proper fibre maintenance

Follow the washing instructions (temperatures and dosage) on the laundry detergent packaging

Perform a pre-wash in cold water without laundry detergent to remove any residual product used during cleaning operations

Recommended use of professional textile laundry detergent

Do not use fabric softener

Do not use laundry detergents with Ph > 11

The use of laundry nets is recommended to speed up and make laundry operations more hygienic

Specific mop instructions



Washing temperature max 90° C, recommended 60°



Bleaching possible, do not use chlorine



Tumble dry or in a dryer possible with low program



Related products



Uni System frame



Telescopic handle



Nickita Dry



Dry wringer